


16 Spare parts



| No. | Spare part                           |
|-----|--------------------------------------|
| 01  | Plastic hood                         |
| 02  | Motor housing                        |
| 03  | Induction motor incl. cable & plug   |
| 04  | Motor protection grille              |
| 05  | Heater 1915 W incl. connection cable |
| 06  | Main isolation plug N / E / L        |
| 07  | Power cable to plug                  |
| 08  | Cover screw                          |
| 09  | Hinge pin                            |
| 10  | Print control cover                  |
| 11  | Print control / HF radar sensor      |
| 12  | Discharge grille                     |
| 13  | Adhesive Rez logo                    |